



CWTT Manual Lab Guide



A **CODED WIRE TAG (CWT)** is a small piece of wire etched with a code and injected into snouts of juvenile salmon and steelhead


LAB STATION ESSENTIALS

1



CUTTING SETUP

V-DETECTOR




ISOLATE

2

[A] Thaw & clean head/snout

[B] Confirm presence of CWT with V-detector



Always make cuts with tissue sample in most stable position


Only divide tissue that produces a signal

[C] Isolate CWT by cutting

1 Make series of cuts to reduce size of sample

2 Run tissue sample by V-detector to confirm CWT


3 Repeat cutting tissue in halves & scanning until CWT is isolated



READ & RECORD

3


Identify CWT code and attach CWT to reading/recording sheet



STORE

4

Sort and file reading/recording sheets with attached CWT



For more detail, scan code for CWT Recommended Procedures Documents

Pacific States Marine Fisheries Commission © 2024



Clean and organize the lab workspace before and after CWT extraction.